

Finger Snaps Cable Guide

Adding Finger Snaps Cable Guides onto a CPI cabling section is as easy as snapping your fingers. The unique design provides the critical cable guides needed to transition from the horizontal pathway into a CPI cabling section (VCS Vertical Cabling Sections or CCS Combination Cabling Sections).

- Plastic cable guides that easily retrofit onto CPI cabling sections
- Resilient plastic material ensures long lasting, quality construction
- Extra-wide and contoured guides allow smooth transition of the cable from the horizontal pathway into a CPI cabling section
- 1U cable guides are designed for fanning and managing patch cords or cables
- Meets UL 94V-0 Flame Resistant standards



ORDERING INFORMATION

Part Number	Description	Shipping Weight lb (kg)
12370-001	Finger Snaps, Pack of 2, Black	1 (0.5)
12370-002	Finger Snaps, Pack of 12, Black	2 (1.0)

For product CSI Specs, visit the Support & Downloads page on www.chatsworth.com.

US & Canada

+1-800-834-4969
 Toronto, Ontario, Canada
 +905-850-7770
 chatsworth.com
 techsupport@chatsworth.com

Latin America

+52-55-5203-7525
 Toll Free within Mexico
 01-800-01-7592
 chatsworth.com.co

Europe

+44-1628-524-834
 chatsworthproducts.co.uk

Middle East & Africa

Dubai, UAE
 +971-4-2602125
 chatsworth.ae

Asia Pacific

+86 21 6880-0266
 chatsworth.com.cn



CHATSWORTH
 PRODUCTS